

## DCR.SR | Injector gaskets slide hammer



### Description:

- To pull injector gaskets blocked at the bottom of the injector well.
- Avoids cylinder head removal.

	<b>DCR.SR</b>
Weight [Kg]	1.63